

voestalpine BÖHLER Edelstahl GmbH & Co KG www.voestalpine.com/bohler-edelstahl

voestalpine

ONE STEP AHEAD



模具製程中的抛光 POLISHING IN MOLD MAKING

THE SURFACE AS A MIRROR OF TIME

But what do they look like, the modern, future-oriented surfaces? Aesthetic, high-quality, robust, easy-care, with top-finish? The requirements to the perfect outer skin are varied. Likewise the fields of application.

The polishing ability of steel for certain application fields is of high importance. Especially in the plastics processing industry very high expectations are often placed on the surfaces of the tools.

The highest surface quality of the tools offers many advantages:

- Highest quality surfaces of plastic parts
- » Good release properties (easy ejection) of plastic parts » Improved optical properties (e.g. for glasses, lenses, flat screens, headlights in the automotive industry)

Highly polished surfaces also offer technological advantages:

improved corrosion resistance

Polished surfaces tend to have much smaller corrosive attack than ground surfaces

Improved security against breaks or cracks

A polished surface has a higher endurance strength and has lower notch effects than ground surfaces. This results in an increased tool life.



表面如鏡、映照出長時間的努力

現代化,未來取向的鏡面看起來應該是什麼樣子?

是美觀·高品質·堅固·容易保養?完美表面的需求與其應 用範圍一樣均為多樣性的。

在特定的產業領域中,鋼材的拋光能力極其重要。尤其在 塑膠財出業中模具的表面時常被以高標準檢視

最高品質的模員表面有以下幾項優勢:

- "製造出最高表面品質的塑膠部件
- » 良好的脱模性能(易於頂出)
- 提高光學性能(計對如: 眼鏡・鏡片、液品螢幕、車燈等應用)

高抛光的老面也提供技術上的優勢

» 提高抗腐蝕性

抛光表面一般來說比研磨表面更不易受到腐蝕攻擊

» 提高抗斷裡或抗破裂的能力

抛光表面有較高的耐久性,相較於研磨表面有較低的缺口 效應(較小的面粗度 Ra),因此有較好的模具影命



良好抛光性鋼材之條件

REQUIREMENTS FOR STEELS REGARDING GOOD POLISHABILITY

Important parameters for the polishability of steels are the level of purity, the homogeneity of the microstructure and the size or respectively the distribution of carbides and other hard constituents in the steel matrix. Especially inhomogeneities can cause significant problems in polishing.

The homogeneity and purity of steel is significantly influenced by the manufacturing process. Primarily the melting technology as the first step of the production is crucial.

With open melting, oxide inclusions, with larger blocks, cannot be completely ruled out. But not only the size and quantity of inclusion are important for the polishing result, but above all the type of inclusion, which depends on the deoxidation process in steelmaking. Disadvantageous are larger, hard and brittle oxides, as they are "polished out" during the polishing process and thus pores can be left behind.

影響鋼材抛光性的重要因素包含鋼材清淨度。微組飾均質性 以及碳化物及基地中其他硬質成分之顆粒大小及分傷等,尤 其是微組織若不均勻會在拋光過程引起嚴重的問題。 鋼材的均質性及清淨度受製造過程影響很大,特別是製程中 第一步的燒鋼技術尤其重要。 A modern steelworks technology with corresponding secondary metallurgy reduces the oxygen content and thus the oxide content in the steel so far that critical inclusion sizes can be minimized. Block formats adapted to the final dimensions and a heat treatment appropriate to the material reduce segregations, and therefore compensate the differences in hardness, so that homogeneity differences hardly influence the polishing result.

In principle, the segregation state and thus the homogeneity of the steel can be improved by remelting processes such as vacuum arc remelting (VAR) or electroslag remelting (ESR / PESR). At the same time, non-metallic inclusions are minimized in these processes. The best level of purity is achieved by melting in the vacuum induction furnace (VIM) or remelting under vacuum (VAR).

在開放式的熔煉過程中,較大塊的鋼錠無法完全排除氧化物的 夾雜物。除了夾雜物的尺寸及數量外,夾雜物的種類也會影響 拋光效果,而短些都取決於煉鋼過程中的除氧程序。大顆,堅 硬及脆質的氧化物在拋光過程中易被按出,留下細孔。

現代化的燒觸技術和相應的二次糖煉技術可降低鋼中的氫含 量。從而降低鋼材中的氧化物含量,使有害夾雜物之尺寸最小 化。採用與最終成材尺寸相近的鋼錠以及適當的熟處理能夠減 少偏析以及硬度落差,使組織均勻性的差異不至於影響描光的 結果。

可以通過諸如真空重熔(VAR)或電道重熔(ESR/PESR)的重 熔工藝來改善鋼材的偏析。從而改善均勻性。 同時。在重熔過 程中能將非金屬介在物減至最少。 通過在真空感應爐(VIM) 中熔煉或在真空下重熔(VAR)可以達到嚴佳清淨度。

影響抛光性之因素

INFLUENCING FACTORS

ON POLISHABILITY

鋼材品質

- » 熔煉過程對鋼材的清淨度影響重大
- » 鋼材中的介在物可能比周圍的材料 軟,從而導致組織不均勻
- 通常介在物的尺寸為幾微米,並具有 細長的形狀

合金組成

- » 在組織中形成硬度差異
- * 導致組織不均勻
- » 品體形態導致表面剝離

How the alloying design influences the polishability shows the following example:

In the case of steel 1.2316, the hard carbide phases embedded in the soft delta ferrite zone give a more irregular polishing result. In return, BÖHLER M303 EXTRA offers a uniform polishing pattern and thus a clear advantage compared to the standard.

以下範例顯示合金設計如何影響激光性:

觀察 1.2316, 嵌入在較軟 δ 肥粒鐵區 域的硬質碳化物使得拋光結果較不均 勻,另一方面,百 黨 鍋 的 M303 EXTRA 能夠提供更為均勻的拋光結 果。與標準 1.2316 產品相比明顯較為 優勢。

STEEL QUALITY

- ... The melting process is decisive for the purity of steel
- Inclusions in steel, mostly sulphidic, can be harder than the surrounding material and thus lead to elutriation
- » Often, inclusions are several microns in size and have elongated shapes

ALLOYING COMPONENTS

- » Form hardness differences in the structure
- Lead to elutriation

1.2316


in crystal form lead to breakouts of the surface

Surface comparison 表面比較

Surface profile

數 8 阳粒浓压域 soft 3 ferrito zone abrasive hard phase 惧的阳离牦柜

BÖHLER M303



homogeneous surface structure 均勻的表面組織





MANUFACTURING PROCESSES

Remelted steels

have the following advantages compared to conventionally produced steels:

- Uniform primary structure and extensive absence from block segregation and internal defects due to solidification
- » Low crystal segregations and thus more uniform microscopic microstructure
- » Reduced quantity and size as well as better distribution of non-metallic inclusions (better level of purity)

Powder metallurgically produced steels

are mostly high-alloy tool steels and have isotropic properties as well as a fine structure. The carbides are homogeneously distributed in the size of a few microns in the matrix, which has a positive effect on the polishability.

製造過程


重熔鋼材 (ESR/ PESR/ VAR)

與非重熔鋼材相比有以下幾個優勢

- 均勻的初析組織。且大幅避免鋼錠固化時產生的偏析 及內部缺陷
- a 結晶偏析低,顯微組織更加均勻
- » 非金屬介在物不但在數量及尺寸上有所降低。在分布 上也較不會聚集(較好的清淨度)

粉末冶金鋼材

多數為高合金工具鋼,具有等向性和細纖的組織。 碳 化物以幾微米之大小均勻分佈在基地中,這對號光性有 正面的影響。





熱處理

為了獲得嚴佳的拋光性能。應非常仔細地進行熟 處理。最好在真空或保護氣體爐中進行。 在熟處 理過程中滲碳或脱碳作用,會造成工具表面的硬 度不均勻,因此有可能會產生較差的拋光性能。 不適合的沃斯田鐵化溫度。持溫時間或過慢的冷 卻速率均會造成晶界析出以及晶粒的粗大。對拋 光性有不良的影響。

HEAT TREATMENT

For best polishing properties the heat treatment should be performed very carefully and preferably in vacuum or protected gas furnaces. Due to carburization or decarburization effects in course of the heat treatment uneven hardness at the tool surface and so worse polishing behavior can arise. Either precipitations at the grain boundaries or grain growth due to unfavorable austenitizing temperatures, holding times as well as slow cooling rates can influence the polishability negatively.

ERODE

Eroded surfaces should be given special attention during polishing. The erosion process causes a structural change on the surface. It can lead to an enrichment of the steel surface with carbon, which in turn leads to the formation of carbides. Furthermore, the rapid local solidification leads to a very brittle martensite. This so generated carbides increase the risk of pinholing, breakouts and orange peel. For a good mirror finish polish, the material must be removed to below the eroding skin.

放電加工

放電過之表面在拋光時需要特別的注意。由於放電過程會導致表面結構 發生變化。放電加工可能使鋼材表面含碳量增加。進而導致碳化物的形成。此外,快速的局部凝固產生硬體之廟田散鐵(放電白層)。這樣生成 的碳化物會增加出現針孔。剝離和橘皮的風險。因此為了獲得良好的鏡 面就光效果,必須將材料去除到放電表層以下。


3種品質等級

3種煉鋼技術

3 QUALITY LEVELS

3 TECHNOLOGIES

BASIC 基礎級



Conventional production


Products made using the electric arc process are designated as conventionally melted materials and are the "basic materials" for ordinary loading, with the following primary properties:

- Banded carbide distribution
- Sufficient cleanliness

常规嫌調方式

常規煉鋼材質為使用電弧工藝生產的產品,是一般用途通常使用的"基本材質"(EAF),有以下幾種主要特性:

- " 帶狀碳化物分布
- 可接受フ清淨度



言語 12%之常規 調權改会相相維 Micro structure of conventional 12% chromium steel

PREMIUM 優良級



ESR / PESR or VAR Manufacture


Products with improved properties can be produced using the ESR/PESR or VAR method. Using remelted materials leads to longer tool life due to:

- High level of cleanliness
- » Low segregation
- ·Larger bar dimensions can be produced with the same carbide distribution
- Uniform dimensional changes
- Improved toughness

ESR/PESR 或 VAR 嫌鋼

使用 ESR/ PESR 以及 VAR 的方式可以生產擁有更佳性能的鋼材。 使用重熔鋼能延長模具壽命的原因:

- 高等級之清淨度
- » 低偏析
- * 即使是產出較大的尺寸也擁有同等級的碳化物分布
- 。均匀的尺寸攀化 >> 較好的韌性



章路 8% 2 ESR 額 種微金相組織 Microstructure of 8% chromium steel in ESR grade

SUPERIOR 特優級



Powder metallurgical production

Materials produced using powder metallurgy are increasingly being used to meet the most stringent requirements with various processing methods. These materials offer properties that meet demanding requirements:

- » No segregation
- # Extremely fine carbide distribution
- Homogeneous properties
- # High wear resistance Wery good dimensional stability
- # High compressive strength » High toughness with high hardness

码末冶金煉鋼

使用粉末冶金所製造的鋼材越來越常用在最嚴苛的條件,因為它能 滿足以下最嚴格的要求:

- "無쏇折
- ■極細環之碳化物分布 ⇒ 萬尺寸穩定性
- · 均質化之組織
- * 高抗壓強度
- n 高耐腐耗性
- » 高韌性及高硬度



粉末冶金銅槽 概全相相関 Microstructure of PM materials

正確之抛光技術 至關重要 THE RIGHT POLISHING TECHNOLOGY IS DECISIVE



TYPES OF POLISHING

The requirements for the surface of a workpiece arise from the intended application areas. It is roughly divided into 4 qualities:

Stroke polish

- » Simple surfaces finishing mostly with abrasive cloths, polishing bench stones or files
- » Used to facilitate demoulding of molded or die cast parts
- Applying with non-visible surfaces, e.g. inside of a housing
- ... As a preparation for nitrating and graining
- » Tools used have a grain size between 320 400

Gloss polish

- » Smaller processing marks are often still visible
- » Surfaces and recesses are shiny
- Especially for visible parts, which should be visually appealing (household items, transparent parts...)
- » Clean shiny surface, controllable with the eye
- » Final polish with felt and diamond pastes between
- 3 6 µm achievable

Mirror finish

- * No visible scratches or cords (crack-free mirror finish)
- # Especially used when products are chrome-plated

Dimensionally accurate and form-true mirror finish

- Highest demands on the surface
- In addition to the crack-free high gloss also the adherence with the macrostructure is required, i.e. flatness, sharp edges and angularity

抛光的類型

不同的應用領域對於工件的機光表面要求也有所不 同,大致上可以分成 4 種等級

打底抛光

- » 簡單表面-主要用砂布·拢光台石或锉刀進行抛光
- n用於輔助模製或壓纏零件的脫模
- » 使用於不可見的表面,例如外置的內面
- 。作為氮化及咬花的前置準備
- w 拋光工具的晶粒度在 320-400 之間

光澤聯光


- » 較小的加工痕跡仍然可見
- »表面和凹槽有光澤
- 用於可見部分,需要視覺上吸引人,例如家庭用品,透明件
- » 乾淨發亮的表面,眼睛可識別
- » 最終鉱光使用毛氈和鑽石膏可達到 3 至 6μm

袋面抛光

- »沒有可見的刮痕或線條(無製紋的鏡面抛光)
- *特別用在總路產品

尺寸及形狀精確的鏡面描光


- ·對表面的最高標準要求
- »除了無裂紋的毫光澤度外。猿需要與宏觀結構保持
- 一致。例如平整度。尖貌的邊角和棱角



載體材料/抛光工具之影響

INFLUENCE OF CARRIER MATERIAL / POLISHING TOOL

The hardness of the carrier material and the size of the polishing grain can be decisive for the roughness depth of the surface to be processed. The greater the penetration depth into the polishing tool at same grain size, the lower the penetration depth into the workpiece surface or the cutting performance of the polishing agent. The adhesion of the grains in the polish carrier is crucial for the polishing result. If the grains adhere firmly to the polishing agent carrier, the cutting process is favored and rolling of the polishing agent on the workpiece surface is avoided. The stickiness of the grains can in turn be influenced by the processing pressure or the liquid used.



增強切削性能

Requirements for a successful polishing are:

- » Proper rough grinding and finishing
- » Selection of suitable polishing tools and polishing pastes
- « Avoidance of overpolishing
- » Avoidance of high contact pressures
- » Careful care and cleaning of the polishing tools
- « Cleanliness (best cleanroom-like conditions)

載體材料的硬度和越光顆粒的大小對於工件表面的組變度 的深度有決定性的影響。在相同前度下進入拋光工具的渗 透深度越大,刻入工件表面的深度或拋光劑的切削性能起 低。顆粒是否可以黏附在拋光載體關鍵性地影響拋光結 果。如果顆粒牢固地黏附在載體上,則有利於切割過程, 並且避免了拋光劑在工件表面上的滾動。顆粒的黏性又會 受到加工壓力或所用液體的影響。

成功避光的條件:

- 。 適當的研磨以及績加丁
- 選擇合適的抛光工具和抛光膏
- ·避免過度拋光
- n 避免過大的接觸壓力
- n 仔細保養和清潔拋光工具
- n 清潔度 (最好為無壓室)



相信 您的眼睛 LISTEN TO YOUR EYES

POLISHING PROCEDURE

Due to the mutual influence of the many influencing factors, it is not possible to draw up general guidelines for the creation of a polished surface. The selection of the individual work steps and the respective polishing agents and tools is primarily determined by experiments and experiences. The following polishing guide represents a common sequence of operations from machining to polishing.

Depending on the quality and processing of the starting surface (eroded, milled or ground), an abrasive wheel with a grain size of 320, 400 or 600 is chosen to completely remove the traces of prefabrication. An optimized polishing result is achieved by sandblasting after the finishing, whereby the surface is compacted.

抛光的程序:

由於拋光結果會受許多因素的交互影響,因此無法建立一個魀光 程序的萬用通則,各工序以及使用的抛光劑和工具仍需取決於實 驗結果與經驗。以下拋光建議為機加工到拋光之常見操作順序。

根據初始表面(放電加工,就削或研磨)的品質和加工。鑑擇顆粒為 320,400 或 600 之砂輪去完全消除租加工痕跡。完成後 再通過順砂處理可辨到過性並光效果,從而使表面緻密。 The polishing process follows in several steps. Starting with a harder carrier such as hardwood, brass or plastic with a paste of about 15 microns (roughly corresponds to an abrasive grain of 1000-1200). All traces from the previous step should be removed. Subsequently, the hardness of the carrier / tool is maintained but the grain of the paste is reduced e.g. 9 μ m. After this step, the carrier can be changed to a softer medium such as e.g. felt or softwood. This scheme is repeated until finally the grain size 1-3 microns with felt or a flocced cloth is used

抛光過程原則上有以下階段。先以較硬的載體(例如:硬木。 黃銅或塑膠)開始,搭配約15 微米的抛光劑(大約等同1000-1200 磨粒顆粒),前一步驟所造成的痕跡必須完全消除。隨 後載體可以繼續使用,但抛光顆粒需變小(如至9 微米)。接 下來可將載體改變為較軟的介質。例如毛氈或軟木。重複這 個模式。直到最後使用毛氈或絨布並且顆粒尺寸為1-3 微米 為止。

Starting 初始 -> surface 表面	Polishir stone o	ng bench or linen	描光油花 或亞爾希		 計畫或要本搭配提光頁 Emery cloth or hardwood → with paste 	数木或塑光毛雕 Softwood or polishing felt →	抛光聚成布 Polishing felt or cloth
Eroded 放電	K320	K400	K600	K800	K1000 15 µm	6 µm 9 µm	3 µm
Finely milled 组铣削							
Fine ground 超研磨	(
R _a (µm)	0.4	0.3	0.2	0.1	0.06	0.03	0.02
R _z (µm)	3.2	2.3	1.2	0.7	0.4	0.2	0.15

CLASSIFICATION 抛光缺陷之 OF POLISH DEFECTS 分類



The content "Classification of polishing defects" has been provided by courtesy of the Fraunholer institute for Production Technology IPT.

Source: PROCESSSTRATEGIES FOR DEFECTFREE POLISHED STEEL SURFACES, pages 9-15, Fraunihofer Institute for Production Technology (PT

"強光缺陷的分類" 之內容由 Fraunhofer Institute for Production Technology IPT 经橡型性

資料末澤 PROCESSTRATEGIES FOR DEFECTFREE POUSHED STEEL SURFACES, pages 9 – 15, Fraunhofer Institute for Production Technology PT

LAMINARY DEFECTS 片狀缺陷

Scratches

Non-directional flat recesses, mostly caused by the cutting edges of the polishing particles or foreign particles (depth ~ roughness Rt).

Tips

- Depending on the requirements of the surface fine scratches can persist
- » Pay attention to the cleanliness of the environment, that no foreign particles cause scratches
- » Final polishing with small abrasive particles

刮痕

無方向性之平凹,主要是由抛光顆粒或異物的尖銳邊緣引起的 (深度~粗糕度 Rt)。

NAME OF

- » 根據表面的要求, 細小划痕可能可被接受
- > 注意環境的清潔、不要有異物引起刮擦
- »用小磨料颗粒進行最終抛光

Orange peel

Fine valleys and hills give the appearance of an orange peel. Excessive pressure or too long polishing time can cause such a defect.

Tips

- » Work with low pressures
- * Do not polish too long (* overpolish *)


橘皮

細小的凹凸呈現出橘皮。 力道過大成拋光時間過長都會導致此 類缺陷。


秘籍

- » 使用較小的力道
- » 不要過批


Orange Peel 穩皮



Pitting Intin



Relief 起伏缺陷



Mist

Less shiny surfaces. Mist may result from deposits of the polish.

Tips

- » Use pH-neutral polishes that do not cause a chemical reaction.
- Work with low pressures to prevent the polishing grains from being pushed in

霧面

較不光澤的表面, 繳光劑的沉積可能導致霧面

秘訣

- » 使用酸酸值中性的提光劑 · 辦免化學反應
- 使用較小的力差避免拋光顆粒過度擠壓進拋光表面

Pitting

Surface pitting means many small holes that are spread over the entire surface.

Tips

- » Keep pressure constant
- » Short polishing steps, cleaning in between and good dry to avoid corrosion

點蝕

許多小點遍佈整個表面

秘訣

- 使用固定不變的力鏈描光
- 縮短抛光步驟,每步驟之間要清潔並維持乾燥避免腐蝕

Relief

Differences in the removal of individual phases due to different material phases (hard / soft).

Tips

- » Before polishing, make sure that the material structure is as homogeneous as possible in order to keep the different material phases low
- » When polishing, choose a tool that is as hard as possible, so that the material phases are removed evenly despite different hardnesses

起伏缺陷

模具材質有不同硬度相,導致不同相的組織在提光後被移除 的程度不一

秘註

- » 拋光前請確認材質組織是否均勻。確保減低相間之表面落 差
- » 拋光時,請盡可能錯擇最硬的工具,即使材料硬度不均仍 能平均的移除表面

形狀偏差 FORM DEVIATIONS

Edge radiusing

Undesired material removal on workpiece edges.

Tips

- » Use suitable polishing tool: hard polishing cloth with low impact resilience
- » Reduce pressure

提角圆弧

提角遭非計畫性的去除

秘訣

- 使用摘合的坳光工具:抗衡擊力低的硬質拋光布
- w減少拋光力道

Ripple

According to DIN EN ISO 8785, the ripple is a deviation of the actual geometry in the millimeter to centimeter range. It mainly occurs during manual polishing.

Tip

 Homogeneous pressure distribution during the polishing process to achieve a uniform removal

波纹

根據 DIN EN ISO 8785 的定義,波紋是 mm 到 cm 左右大 小幾何形狀的偏差,通常發生在手工拋光

1000年出

使用均一的力道進行拋光,以期達到一致的去除效果

CLASSIFICATION 抛光缺陷之 OF POLISH DEFECTS 分類



LOCAL DEFECTS 局部瑕疵

Very deep scratches, sharp edges, mostly due to high material stress.

» Avoidance during the polishing process is not possible, because it is more a material error. For this reason, the workpiece should be examined in advance for invisible cracks / material defects.

非常深的刮痕,有缝利的缝缘,主要是軟大的材料應力所致。

»由於鑄是一個材質本身的問題,因此在拋光過程中無法發 免, 顺事先接查是否有不可見的際傷或材質問題

Holes / Breakouts

Unevenly shaped holes. They are formed where non-metallic inclusions and carbides are present in the microstructure.


- » Work with low pressures to avoid tearing
- * Use the most homogeneous steel structure as possible in advance, if the surface quality requirements are very high (purity
- w Use a napless polishing cloth, as this promotes tearing out of carbides and inclusions
- » Low pressures already during pre-grinding and fine grinding

孔洞/剝離


不規則的孔洞、產生在非金屬介在物或碳化物的位置

- » 使用較低的力道,減少拔扯的可能
- n 如果對表面要求很高,讀盡可能使用組織最均勻,清淨度量好
- » 使用無絨毛的抛光布。因為絨毛會加強碳化物和夾雜物的拔扯
- » 研磨或精修時使用低壓/較小力適


Holes/Breakouts 孔洞/倒鏈



Scoring 刮痕



Impurities 腱質



Scoring

Deep, directional tracks (depth >> roughness Rt). They arise when the processing traces of the previous step (usually the preprocessing) were not completely eliminated.

Tip

» Always remove pre-processing marks thoroughly

刮痕

深並有方向性的刮痕(深度>粗糙度 Rt),上一步(通常在前加 工)的處理痕跡沒有完全消除而纏致

秘訣

» 徹底去除粗加工痕跡

Peak

Uneven elevations. These are either workpiece material that has been unevenly removed during the polishing process, or polishing particles that have pressed into the surface during the polishing process.

Tips

- » Homogeneous pressure distribution
- » Use high viscosity polish

突起

表面凹凸不平,有可能是加工力缝不均。或抛光颗粒押入表 面所致

秘納

- » 加工力遊維持一致
- * 使用高黏度抛光劑

Comet tails

Inclusions that have a "tail" and therefore the appearance of a comet.

Tips

- » In the metallographic sample preparation, it should not be possible to polish in synchronism when comets appear
- » When polishing manually, a higher speed can prevent comet formation

彗星痕

可見的介在物,有尾巴並且外親如彗星一般

Salet.

- » 準備金相標本時, 黨彗星出現時不應該同步做拋光
- 事動抛光時,快一點的速度可以預防彗星痕的出現

Impurities

A hole filled with foreign material (dirt particles or material removal products).

Tips

- # Working clean
- w Use low pressures to prevent the particles from getting into the hole

雞智

出現孔洞並有異物在其中(髒污的顆粒或刨除的碎屑)

秘訣

- » 工作環境保持清潔
- » 加工使用較小力道防止碎周進入孔洞中

其他瑕疵 FURTHER DEFECTS

Corrosion

Reaction of machined workpieces with substances from the environment. Corrosion often results from poor drying after cleaning.

Tips

- Clean and dry samples immediately after processing.
- Store samples dry

腐蝕

加工過的工件與環境物質的反應。 腐蝕通常是清潔過後工件 不夠乾燥所造成的。

秘註

- 拋光處理後立即清潔並乾燥工件
- n將工件儲存在乾燥環境中

Burn mark

Fire pattern on the workpiece surface. Caused by too much heat during the polishing process and often causes damage to the surface structure (microcracks).

Tip

Use sufficient coolant / lubricant during the process

燒焦痕

工件表面有燒焦紋。 在據光過程中由於過熱而引起。並經常 損壞表面結構(微裂紋)。

粉點

» 在過程中使用足夠的冷卻液/潤滑劑

Discoloration

Area that appears differently (in most cases dull) to the actual surface. Topographically, there is usually no difference.

Tips

- Use neutral polishes to avoid damage to the surface
- For soft material, work with low pressures to prevent polishing grains from settling in the surface

變色

表面有部分區域看起來不同(多數看起來較黯淡),但就型貌測 量上,高低平擊並無不同


拉拉

- » 使用中性批光劑,避免損壞表面
- » 對於柔軟的材料。請在使用較小力道加工以防止拋光顆粒 沉澱在表面上



For post-processing of BÖHLER tool steels joke recommends:

ENESKAmicro from joke - the new generation of grinding, polishing, milling and deburring.



tool holder & motor produceroverall compatible

refined tool holder

> highest concentricity

in accordance to IP 54


extremly silent

> 100 % Made in GERMANY

highest clamping force worldwide

30 % more power

20 % higher endrotary speed



joke Technology GmbH

Asselborner Weg 14-16 • D-51429 Bergisch Gladbach Tel. +49 (0) 2204/839-0 • Fax +49 (0) 2204/839-60 Mail info@joke.de • Web www.joke-technology.de





抛光性評估 ASSESSMENT OF POLISHABILITY

The surface quality of forming parts of compression or injection molds is often defined by indications such as "polished" or "mirror polished", without these terms being defined in standards by measurable variables. Although a good reproducibility can be achieved by specifying the processing steps required for a certain surface quality, however, no guarantee of the predefined polishing quality can be given by the before mentioned influences.

The visual impression of a smooth, shiny surface is composed of a variety of optical and physiological effects. As a result, the correlation of the visual impression with quantitatively measurable variables is difficult. Therefore, the subjective assessment of the surface finish by experts is widespread.

壓縮或射出模具成型零件的表面品質通常由"抛光"或"鍍面抛光"等名詞定義, 而這些術語並沒有通用的可測量標準。即使透過制訂標準加工程序可以良好地再現 相當程度的表面品質,但仍無法保證抛光结果不受上述因素的不良影響。


光滑,有光澤的表面視覺印象是由多種光學及物理效應而構成,因此視覺印象無法 作為可測量的標準,導致抛光表面的品質判斷通常流於主觀標準。

百樂鋼種之拋光性 POLISHING OF BÖHLER GRADES

The following assessment of polishability was conducted with experienced polish specialists at joke-Technologies. The assessment is based on the basic suitability of the material for mirror polishing and the time required for polishing.

The assessment refers to small round dimensions (50-80 mm) and polishing transverse to the grain direction and represents a principal comparison of the polishability of the grades. In actual work-pieces, deviations from the polishability due to the dimension, the removal position and the structural coherency between the fiber direction and surface of the workpiece to be polished may occur. In addition, the polishability depends on the type of polishing process and the sequence of polishing steps 以下是 Joke-Technologies 經驗豐富的拋光專家針對拋光性的測試評估。以鏡面拋光材料的基本適用性以及越光所需的時間作為標準

該測試使用較小的圖形樣本(50-80毫米),以垂直於晶粒方向進行拋光。做不同韻種之悶拋光性能的比較。在實際的工件中,由於尺寸、拋光位置和纖維方向與工件表面之間的相互影響,可能會引起拋光性能的偏差。另外。拋光性取決於拋光擊程的類型和拋光步驟的顯序



BCHLER K110	*
DOHLER K340	**
DOUBLE K340	**
BCHLER K390	****
BCHLER K490	****
BÖHLER K600	****
BÖHLER KBYS	****
DOMESTIC \$390	***

熱作調種 Hot work tool steels

BOHLER W300	***
BOHLER W302	**
BÖHLER W350	***
BOHLER W360	***
BÖHLER W400	****
DONIEL W402	****

可硬化之耐腐蝕不銹鋼 Hardenable, corrosion resistant steels

BOPLAST	***
SOPLAST	****
BOPLEST	**
BOHLER MIAS MICHOLEGAD	****
BOHLER M390	***
DESTRUM NAME	*

非耐腐蝕之預硬網種 Prehardened steels.

non-corrosion resistant

耐腐蝕之預硬不銹鋼種 Prehardened steels, corrosion resistant

EXTRE	****
EXTRA	****
BOHIER M314	**
BÖHLER M315	*
ESCENSION	***

The comparative assessment of polishability takes place within material groups.

A comparison of the evaluation of grades of different groups does not make sense.


可抛光性的比較評估是在各綱種分類內進行。 比較不同分類的評估結果是沒有意義的。



案例分析 CASE STUDIES

The following comparison illustrates exemplarily the time effort reaching a mirror-polished surface starting from a pre-ground surface.


下表為各綱種從組研屬到鏡面抛光完成所花費的時間比較



BOHLER W300

STRUCK CO.

1.2343, H11 ESR



抛光步骤 Polishing steps

K600 25 μm 14 μm 9 μm 6 μm 3 μm

coarse 組 fine #

BOHLER W400

梧濟工業股份有限公司

http://www.wujii.com.tw/



台中市南屯區工業區 20 路 1 號

TEL: +886-4-23593510 FAX: +886-4-23593529

E-mail: wuji2297@ms24.hinet.net

泰山廠

新北市泰山區文程路 56 號

TEL: +886-2-85311121 FAX: +886-2-85311125

E-mail: wujiitaishan@wujii.com.tw

台南廠

台南市永康區鹽行里中正北路 318 巷 16 弄 36 號

TEL: +886-6-2544168 FAX: +886-6-2544178

E-mail: wujiitainan@wujii.com.tw

本洲廠

高雄市岡山區本工五路 50 號

TEL: +886-7-6226110 FAX: +886-7-6226635

E-mail: sin.wu0496@msa.hinet.net

冷作銅

台中市南屯區工業區 20 路 42 號

TEL: +886-4-23597381 FAX: +886-04-23597382 E-mail: cnc@wujii.com.tw

華晟特殊鋼鐵

新北市新莊區新樹路 302 巷 23 號

TEL: +886-2-22048125 FAX: +886-2-22035597 E-mail: hc23@wujii.com.tw

高雄麻

高雄市鳥松區美山路 6 號

TEL: +886-7-7336940 FAX: +886-7-7336934

E-mail: kaowujii@wujii.com.tw

熱處理廳

台中市南屯區工業區 19 路 9 號

TEL: +886-4-23590345 FAX: +886-4-23591102

The data contained in this brochure is merely for general information and therefore shall not be binding on the company. We may be bound only through a contract explicitly stipulating such data as binding. Measurement data are laboratory values and can deviate from practical analyses. The manufacture of our products does not involve the use of substances dot involve to be eith or to the come layer.



voestalpine BÖHLER Edelstahl GmbH & Co KG

Mariazeller Straße 25 8605 Kapfenberg, Austria P. +43/3862/20-6046

F. +43/3862/20-7563 E. info@bohler-edelstahl.at www.voestalpine.com/bohler-edelstahl

